










Output Wiring Onboard 24VAC Contactor



NOTE 1




GREY 19 CONNECTION 24VAC
DISTRIBUTION BLOCK (NEUTRAL)
LOCATED ON DIN RAIL IN
CONNECT CONTROLLER ENCLOSURE

1. Ensure the Contactor coil is rated for a 24VAC control signal and that the contact side of the Contactor is rated for use with your device's electrical ratings.

2. Power for the controlled device should run through the contact side of the Contactor and should not be connected to the Connect Controller.

3. Always consult and follow your Contactor manufacturer's IOM and wiring diagrams.



NOTES:

1. ENSURE BLUE JUMPER IS INSTALLED.